
ASSEMBLY INSTRUCTIONS

LOKRING® tube connection assembly version 00


(The assembly version is determined on the basis of the last two figures in the article name. Example: LOKRING 6 NK Ms 00)






01. Emery cloth **02.** LOKPREP 65G **03.** LOKRING connector **04.** Hand assembly tool









 \emptyset = outer tube diameter






Insert both tube ends into the LOKRING connector (03) until the tubes reach the inner stop . Rotate the LOKRING connector (03) through 360° to distribute the LOKPREP 65G (02) evenly. Respect the correct curing time of the LOKPREP 65G (02).





Position the jaws of the hand assembly tool (04) squarely onto the rings of the LOKRING connector (03). In a controlled manner use the hand assembly tool (04) to press the rings onto the connector ensuring that the tubes remain seated against the centre stop of the LOKRING connector (03) throughout this process. Once both rings are flush to the centre stop of the connector the joint is complete. Carefully remove the hand assembly tool (04) from the LOKRING connector (03).





EXAMPLES AS ASSEMBLY AID

LOKRING® tube connection assembly version 00









CURING TIME OF LOKPREP 65G

LOKRING® tube connection assembly version 00

